



SEALED IN QUALITY

MXS 38

Fitting Instructions

- 1.** Remove rubber seal from aluminium sill section. Measure width between inside faces of the doorframe rebate and cut aluminium section to this size, cutting at opposite end to the replacement seal.
- 2.** Cut the rubber seal to the same length as the aluminium and reinsert into the groove in sill.
- 3.** This sill requires an under door clearance of 28mm. If necessary, remove door and trim to allow for this, ensuring bottom of door is smooth to avoid damage to rubber seal.
- 4.** Position the assembled sill between the doorframe and mark fixing points through countersunk holes. Remove sill, drill fixing holes and insert plugs.
- 5.** Apply sealing compound (Exitex Elast-O-Sealant) to underside groove at rear of sill where sill comes into contact with doorframe. Ensure rubber seal at front is in place and screw sill into place.